

# The Atago PAL-1 Pocket Refractometer



## Application

The PAL-1 is small and compact enough to fit in your pocket. Measurements can be made anywhere with ease.

- Outdoors at fruit and vegetable farming orchards
- Indoors at beverage and food factories
- At fruit and vegetable markets or supermarkets
- At restaurants or shops
- At junior high, high schools or universities as a course material



## Specifications:

Measurement range.....	Brix 0.0 to 53.0%
Resolution.....	Brix 0.1%
Measurement Accuracy.....	Brix +/- 0.2%
Measurement Temperature.....	10 to 40°C (Automatic temperature compensation)
Power Supply.....	2 x AAA Batteries
Waterproof Protection.....	IP65
Dimensions and Weight.....	55 x 31 x 109 mm, 100 g

## Measuring method



1 Apply 2 - 3 drops onto the prism surface



2 Press the START key



3 Brix % value displayed in 3 seconds!

# WACO

## WILKENS-ANDERSON COMPANY

4525 West Division Street, Chicago, Illinois 60651  
Phone: 773-384-4433, 800-847-2222, FAX: 773-384-6260